

# INSTRUCTIONS AND USER GUIDE

Item No. 241867
Printer Mount Kit Quick Release Dock with Key Lock for Zebra ZD420 ZD620 ZD621

Zebra ZD420 / ZD421 / ZD620 / ZD621



**DO NOT** attach anything to the mount face plate until after installing the mount to the dashboard. Doing so makes it more difficult to install the mount to the dash.

#### Item No. 241867



#### Attention:

Carefully read all instructions and review the images before installing this product. **Do not** attach anything to the mount face plate until after installing the mount to the dashboard. Doing so makes it more difficult to install the mount to the dash. **Also,** our installation instructions are often printed prior to the last year of a ProClip mount listing. The year listing we show on our web site should be the most accurate listing.

#### Important

Self-installation instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical ability required to properly perform an installation. ProClip USA, LLC. shall have no liability for damage or injury resulting from the installation or use of any ProClip or third party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to allow a vehicle to be operated safely and without distraction. ProClip USA, LLC. product warranties do not cover the installation, removal or reinstallation of any product.







# **STEP 1 OF 8**

#### **Included Fasteners:**

This mount kit includes fasteners for attaching the plate to the printer. It also includes fasteners for attaching the quick release dock to an appropriate pedestal or mount (Not included). Note that the smaller M3 fasteners are to be used with the printer.



#### STEP 2 OF 8

#### **Mounting the Printer:**

This printer mounting plate is designed to fit the Zebra ZD420 and ZQ620 printers. The mounting holes for the Direct Transfer version and the Thermal Transfer version are slightly different. This plate accommodates both.

Both printers are mounted with the M3  $\times$  8MM fasteners that are included. If your printer only uses 3 screws, 1 will be unused and can be saved or discarded.



# **STEP 3 OF 8**

## **Align the Printer Plate:**

To determine how many of the M3  $\times$  8MM fasteners will be needed, flip the printer over and match the hole pattern to the correct printer.

This plate is designed with an airflow channel to ensure the printer vent is not covered. Align the air channel with the vent on the printer, and then lay the plate onto the printer.



#### STEP 4 OF 8

#### Mount the Printer Plate:

With the printer plate aligned, place an M3 fastener into the plate and then fasten to the bottom of the printer using the included Allen wrench.

**Note:** You may only use 3 of the M3 fasteners depending on the model of printer you are mounting.



#### STEP 5 OF 8

## To mount the Quick Release Dock:

Attach the base plate to any AMPS compatible mount using the included fasteners. (Demonstration pedestal not included.)



# STEP 6 OF 8

# **Docking the Printer:**

Insert the printer into the dock by aligning the male block and sliding down. The release lever will click when the dock is in place.



#### **STEP 7 OF 8**

## **Locking the Printer:**

Press the center pin engage the lock. This prevents the release lever from moving and keeps the printer secured on the quick release dock until unlocked.



#### STEP 8 OF 8

## **Un-Locking the Printer:**

Turn the key until the center pin pops out. Press the release tab on the dock slightly and slide the printer up and out.

#### Returns

All returns must be made within thirty (30) days of the delivery date and include proof of purchase, a copy of your original order, or invoice. No products shipped hereunder may be returned without ProClip USA's prior approval. In order to return a product, the buyer must obtain an RMA number (Return Merchandise Authorization Number). Items returned without a valid RMA number may be rejected. Items that are open, used, damaged, or returned without all original components may have a restocking fee applied.

#### **Limited Warranty and Liabilities**

ProClip warrants that the Products will be free of defects in materials and workmanship for a period of one (1) year from the date of purchase. If any Product should become defective within the warranty period, ProClip, at its option, will replace it, repair it or refund the purchase price. Repair or replacement parts or Products will be furnished on an exchange basis and will either be new or reconditioned. All replaced Products shall become the property of ProClip. Warranty service is available to you by delivering the Product during the warranty period to the company it was purchased from or to ProClip at 4915 Voges Rd.. Madison, WI 53718 USA and providing proof of purchase, price and date. If shipped to ProClip, the buyer must first call ProClip at +1 800-296-3212 or e-mail ProClip at returns@proclipusa.com to obtain a return approval and return number. You will bear all shipping, packaging and insurance costs and all other costs, excluding labor and parts, necessary to effectuate repair, replacement or refund under this warranty. For more information on how to obtain warranty service, write, e-mail or telephone ProClip at 4915 Voges Rd., Madison, WI 53718 USA. Tel: +1 800-296-3212, e-mail: returns@proclipusa.com. THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCT WHICH HAS BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE OR AS A RESULT OF UNAUTHORIZED SERVICE. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES FOR THIS PRODUCT. IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT, SHALL HAVE NO GREATER DURATION THAN 1 YEAR FROM THE DATE OF PURCHASE. IN THE EVENT THIS PRODUCT BECOMES DEFECTIVE DURING THE WARRANTY PERIOD, THE PURCHASER'S EXCLUSIVE REMEDY SHALL BE REPAIR, REPLACEMENT OR REFUND AS PROVIDED ABOVE. IN NO EVENT SHALL PROCLIP BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION LOSS OF PROPERTY, ARISING FROM BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY. PROCLIP DISCLAIMS ALL WARRANTIES. EXPRESS OR IMPLIED. OTHER THAN THOSE SET FORTH ABOVE. IN NO EVENT WILL PROCLIP BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, INDIRECT, SPECIAL, PUNITIVE. OR EXEMPLARY DAMAGES. INCLUDING ATTORNEY FEES ARISING OUT OF THE USE OF OR THE INABILITY TO USE THE PRODUCTS, OR FOR ANY CLAIM BY ANY OTHER PARTY, EVEN IF PROCLIP HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Regulatory information: www.proclipusa.com/regulatory.html