



# INSTRUCTIONS AND USER GUIDE

## Item No. 216209 Clamp Mount with 7.4 In. Swiveling Pedestal



**DO NOT** attach anything to the mount face plate until after installing the mount to the dashboard. Doing so makes it more difficult to install the mount to the dash.

Item No. 216209



Attention:

Carefully read all instructions and review the images before installing this product. **Do not** attach anything to the mount face plate until after installing the mount to the dashboard. Doing so makes it more difficult to install the mount to the dash. **Also**, our installation instructions are often printed prior to the last year of a ProClip mount listing. The year listing we show on our web site should be the most accurate listing.

Important

Self-installation instructions and advice are provided for your convenience. It is your responsibility to determine if you have the knowledge, skills, and physical ability required to properly perform an installation. ProClip USA, LLC. shall have no liability for damage or injury resulting from the installation or use of any ProClip or third party products. It is your responsibility to ensure that all products are installed in adherence with local laws and regulations and in such a manner as to allow a vehicle to be operated safely and without distraction. ProClip USA, LLC. product warranties do not cover the installation, removal or reinstallation of any product.



## STEP 1 OF 8

### **#1 and #2 Round Bases**

This product fits the Heavy-Duty Forklift and Pedestal mounts from ProClip. The small teeth match a #1 to a #2 to allow for a perfectly straight fit.



## STEP 2 OF 8

### Swiveling Center Section:

The center wingnut can be loosened to allow both pedestal bases to be independently rotated to get the plates to face the exact position desired. Simply tighten the wing nut after the adjustment.

To adjust the angle of the top and bottom plate, loosen the bolt with the included Allen wrench.

This allows adjustment to all 3 axis to achieve the exact angle and position desired.



## STEP 3 OF 8

### Locknut Replacement

This product comes with lock washers and wingnuts allow this to be locked into a specific position, or provide easy adjustment after being installed.

Simply remove the wing nut or lock nut and replace with the alternative to make each of the adjustment points function as desired.



## STEP 4 OF 8

### **Highly Adjustable and Durable:**

This product can achieve virtually any angle that a typical ball mount system can but provides additional strength and rigidity where needed.



## STEP 5 OF 8

### **Attach the Clamp**

This forklift mount includes a clamp that can accommodate any rectangular surface up to 3.375" x 5.125". Using the included fasteners, determine which screws will be required to span the width needed.

**Note:** Ensure the coupling nut or bolts contact both sides of the bar to prevent them from turning in the plate and ensuring they do not loosen over time.



## STEP 6 OF 8

### **Attach Pedestal Base:**

Attach one side of the pedestal base to the clamp. Either side can be attached and will not result in any difference in adjustment. **Note:** The clamp features a circular pattern of M4 holes to allow positioning as close to the desired angle as possible. Attach the base plate with the included M4 fasteners and lock washers.





## STEP 7 OF 8

### **Attach Swivel Section:**

Adjust the arm based on the desired position of the device.  
Securely tighten the wingnuts to lock the arm in place.



## STEP 8 OF 8

### **Installation Complete:**

This completes the installation of the forklift mount. Note that the fasteners and Allen Wrenches included will allow you to complete this installation without any additional tools.

## Returns

All returns must be made within thirty (30) days of the delivery date and include proof of purchase, a copy of your original order, or invoice. No products shipped hereunder may be returned without ProClip USA's prior approval. In order to return a product, the buyer must obtain an RMA number (Return Merchandise Authorization Number). Items returned without a valid RMA number may be rejected. **Items that are open, used, damaged, or returned without all original components may have a restocking fee applied.**

## Limited Warranty and Liabilities

ProClip warrants that the Products will be free of defects in materials and workmanship for a period of one (1) year from the date of purchase. If any Product should become defective within the warranty period, ProClip, at its option, will replace it, repair it or refund the purchase price. Repair or replacement parts or Products will be furnished on an exchange basis and will either be new or reconditioned. All replaced Products shall become the property of ProClip. Warranty service is available to you by delivering the Product during the warranty period to the company it was purchased from or to ProClip at 4915 Voges Rd., Madison, WI 53718 USA and providing proof of purchase, price and date. If shipped to ProClip, the buyer must first call ProClip at +1 800-296-3212 or e-mail ProClip at [returns@proclipusa.com](mailto:returns@proclipusa.com) to obtain a return approval and return number. You will bear all shipping, packaging and insurance costs and all other costs, excluding labor and parts, necessary to effectuate repair, replacement or refund under this warranty. For more information on how to obtain warranty service, write, e-mail or telephone ProClip at 4915 Voges Rd., Madison, WI 53718 USA. Tel: +1 800-296-3212, e-mail: [returns@proclipusa.com](mailto:returns@proclipusa.com). THIS LIMITED WARRANTY DOES NOT EXTEND TO ANY PRODUCT WHICH HAS BEEN DAMAGED AS A RESULT OF ACCIDENT, MISUSE, ABUSE OR AS A RESULT OF UNAUTHORIZED SERVICE. THIS WARRANTY IS IN LIEU OF ALL OTHER EXPRESS WARRANTIES FOR THIS PRODUCT. IMPLIED WARRANTIES, INCLUDING THOSE OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NON-INFRINGEMENT, SHALL HAVE NO GREATER DURATION THAN 1 YEAR FROM THE DATE OF PURCHASE. IN THE EVENT THIS PRODUCT BECOMES DEFECTIVE DURING THE WARRANTY PERIOD, THE PURCHASER'S EXCLUSIVE REMEDY SHALL BE REPAIR, REPLACEMENT OR REFUND AS PROVIDED ABOVE. IN NO EVENT SHALL PROCLIP BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING WITHOUT LIMITATION LOSS OF PROPERTY, ARISING FROM BREACH OF ANY EXPRESSED OR IMPLIED WARRANTY. PROCLIP DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE SET FORTH ABOVE. IN NO EVENT WILL PROCLIP BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES, INCLUDING, WITHOUT LIMITATION, INDIRECT, SPECIAL, PUNITIVE, OR EXEMPLARY DAMAGES, INCLUDING ATTORNEY FEES ARISING OUT OF THE USE OF OR THE INABILITY TO USE THE PRODUCTS, OR FOR ANY CLAIM BY ANY OTHER PARTY, EVEN IF PROCLIP HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

**Regulatory information:** [www.proclipusa.com/regulatory.html](http://www.proclipusa.com/regulatory.html)

---

### ProClip USA, LLC

4915 Voges Road • Madison, WI 53718 • USA  
Office: +1 608-807-5230 • Fax: +1 920-372-0066  
Toll free: 800-296-3212 • [www.proclipusa.com](http://www.proclipusa.com)